

(GB) English – Installation Instructions

1.Assemble the shelf panel and the back panel.

Align both parts carefully so that there is no visible gap.

Secure them with **3 pcs of M6 nuts**.

2.Attach the lower hanger.

Fix the lower hanger to the shelf panel using **2 pcs of M4 cap nuts**.

3.Attach the upper hanger.

Fix the upper hanger to the shelf panel using **2 pcs of M4 screws**.

4.Mount the wall bracket.

Fix the wall bracket to the wall using the **oval holes** (one vertical on one side, one horizontal on the other).


Use **only one hole from each pair** to allow for easy leveling and slight side adjustment.

Once aligned, you may optionally mark and secure the bracket through the round holes for extra stability.

The **wall plugs and screws are included** in the package.

✓ **Tip:** Always check with a spirit level before final tightening.

⚠ **Important:** Ensure that the bracket is mounted on a solid and dry wall using the included plugs and screws.



Item	Piece	Description	SUM	CAUTION
1	1	Wall bracket	1,032 kg	
2	1	Back panel	2,452 kg	
3	1	Shelf	1,101 kg	
4	1	Bent bracket upper	0,226 kg	
5	1	Bent bracket lower	0,248 kg	
6	1	Painted sheet	0,145 kg	Pre-installed
7	4	Magnet	0,106 kg	Pre-installed
8	2	Cylindrical head screw M4×12	0,006 kg	
9	2	Washer 4	0,002 kg	
10	4	Washer 5	0,014 kg	Pre-installed
11	5	Washer 6	0,014 kg	2 pcs pre-installed
12	2	Cap Nut M4	0,003 kg	
13	4	Nut M5	0,005 kg	Pre-installed
14	5	Nut M6	0,015 kg	2 pcs pre-installed

COSYCANUSA

Kitchen shelf
INSTALLATION

Weight:

5,368 kg