

(GB) English – Installation Instructions

Option A – Floor standing

- 1.Screw the adjustable feet into the threaded inserts at the bottom of the cabinet.
- 2.Adjust the feet until the unit is level and stable.

Option B – Wall mounted

- 1.Mount the wall bracket

Fix the bracket to the wall using the oval holes (one vertical on one side, one horizontal on the other).

Use only one hole from each pair to allow for easy leveling and slight side adjustment.

Once aligned, optionally secure through the round holes for extra stability.

The wall plugs and screws are included.

- 2.Hang the TV cabinet (2 people)

Align the keyhole slots with the wall bracket, slide the cabinet sideways, then lower it vertically until it locks securely.

MDF panel and shelf installation

- 1.Insert the removable MDF panel as shown – it attaches magnetically.

- 2.Partially insert the two M6 screws; do not tighten fully.

- 3.Hang the shelf so that the slots rest on the screws.



- 4.Once seated, tighten the screws completely.

To remove, follow the same steps in reverse order.


⚠ Important: Always ensure the wall bracket is fixed to a solid, dry wall using the included plugs and screws.

Do not attempt wall mounting alone – two people are required.


Option A




Option B



MDF Panel and shelf Installation:



RÉSZLET A



Item	Piece	Description	SUM	CAUTION
1	1	TV Cabinet	12,532 kg	
2	4	Adjustable feet	0,350 kg	
3	1	Wall bracket	2,869 kg	
4	1	Removable MDF panel	1,636 kg	
5	1	Removable shelf	0,661 kg	
6	2	Cylindrical head screw M6x12	0,012 kg	

COSYCANUSA

Snake TV Cabinet
INSTALLATION

Weight:
18 kg